



HOW-TO:

Glue this divided windshield over the FRONT WINDSHIELD (PART NR. 13).

Cut the POWER POD NACELLE (PART NR. 19) at the leading edge of the wing and glue this extensions on it.